# Metal Walk-in
# **Chicken Coop Run**

## Instruction manual
## For specification:2.2m(L)x1.4(W)x1.75m(H)



CE  Please read this manual carefully before assembly

1  x4pcs    995mm pipe

2  x5pcs    1300mm pipe

3  x4pcs    980mm pipe

4  x4pcs    1005mm pipe

5  x2pcs    440mm pipe

6  x1pcs  530mm pipe

D1  x1pcs

D2  x1pcs

D3  x1pcs

A  x6pcs

C  x4pcs

E  x2pcs

F  16mx1

H  x2pcs

I  x3pcs

J  x1pcs    Roof

K  x4pcs

L  x4pcs

M  x6pcs

N  xNpcs

O  xNpcs

# Step 1

Assemble the bottom frame as the below drawing.

# Step 2

Gather pipe "3"×4pcs, insert the pipes into the connectors "C" as the below drawing.

# Step 3

Gather connector "A"×4pcs, and pipe "2"×2pcs, assemble as the below drawing.

# Step 4

Gather connector "A"×2pcs. Pipe "4"×4pcs and "2"×1pcs
Assemble the top frame as the drawing.

# Step 5

Assemble the door with 1 pcs of "D1", 1pcs of "D2", 1 pcs of "D3",
2 pcs of "5" and 1 pcs of "6".

# Step 6

Install the door to the chicken frame with "H"x2 pcs, "I"x3pcs and screws.

# Step 7

Step 1: NO PRE-CUT! Cover around the house, then cut off finally. And tie it to the pipes with strap "N".

# Step 8

NO PRE-CUT! Cover the top, finally cut off. And tie it
to the pipes with strap "N".

# Step 9

Measure the △parts of front and back sides, Pre-cut the wire mesh
for covering . And tie it to the pipes with strap "N".

(Front)                    (Back)

# Step 10

Measure the door size, Pre-cut the wire mesh for covering . And tie it
to the pipes with strap "N".

# Step 11

Put the waterproof cover "J" on the frame, tighten it on the frame with "O".

# Step 12

Put the ground anchor "M" into ground to make the cage more stable and durable.